


OPERATING INSTRUCTIONS MDR-5


Condor pressure switches were built according to the relative and approved regulations of the time period when they were developed and produced and are considered to be safe during operation. However, this device can present risks if it is used by personnel without specialist training, or is used inappropriately or in an unapproved manner. The safety data sheet and the local legal regulations are to be strictly observed. The pressure switches serve the surveillance and control of processes, operations of pumps and compressors in dependence on the prevailing pressure.



*1: For the MDR-5 with buttons, an overcurrent relay is absolutely necessary otherwise the shut off and on mechanism will not work.

Technical Data (DIN EN 60947-4-1)		
Rated operational current le	16 A	
(Ue = 400 V)		
Rated operational power (AC 3)	2,5 kW / 5,5	
Ue =250 V (1~) / 400 V (3~) / 500 V (3~)	kW / 4 kW	
Rated frequency	50 Hz / 60 Hz	
Rated insulation voltage Ui	500 V	
Rated conditional short-circuit current	3 kA	
(Ue = 500 V)		
Pollution degree	3	
Protection class	I.	
Mechanical durability	> 5 x 10 ⁵	
operating cycles		
Maximum mechanical switching	600	
frequency operating cycles / h		
Electrical durability (AC 3)	> 1 x 10 ⁵	
operating cycles		
Rated operating mode (Class 120)	120	
operating cycles / h		
Permissible medium temperature (air)	-5°C -+80°C	
Type "2" H00 / gL	50 A	
Contact material	Silver alloy	
*2: If air out of the tank is released through the released	se valve after shutting	


- *2: If air out of the tank is released through the release valve after shutting off the switch, the non-return valve on the compressor is to be checked.
- *3: The pressure values shown on the label are the factory settings set by Condor. These can be adjusted. See the pressure setting diagram.



The following material are available for flanges:		
Die-cast aluminium	Plastic	Plastic
	with stainless steel connector	with brass connector
Degree of protection: IP 54	Degree of protection: IP 65	Degree of protection: IP 65
Diaphragm: NBR	Diaphragm: EPDM	Diaphragm: EPDM
!!! Watch out for any electrochemical corrosion when connected with other metals !!!		

Caution: Pressure setting is only possible when applying pressure to the switch

Cut-out pressure p





p lower: turn wheel to the left => cut-out

right => cut-out pressure lower





=> cut-in

pressure higher

Δp higher turn wheel to the left => cut-in pressure lower


Spindle


If the spindle moves when turning, lowest possible Δ_n has been reached. In order to loosen, turn wheel the left holding the spindle (p_F = cut-in pressure)




How-to videos: Adjust pressure values - You Tube https://www.youtube.com/watch?v=7RRTp A-VXQ


Pressure diagrams MDR 5






Example: Cut-out pressure p = 4 bar, cut-in pressure p_E between 1.8 and 3.2 bar possible, all values can be adjusted in the grey field.







Condor Pressure Control GmbH

Warendorfer Straße 47 - 51 D-59320 Ennigerloh

Phone: +49 (0) 2587 / 89-0 Fax: +49 (0) 2587 / 89-140 info@condor-cpc.com www.condor-cpc.com

0.0800.0346 - c - 06.11.2017 Operating instruction MDR-5 0.0800.0346 - c - 06.11.2017 Operating instruction MDR-5